
Barrel EMC L1 Input - Low Eta Sum
Entries 7020036
Low Eta Sum
BC101
BC102
BC103
BC104
BC105
BC106
DSM Input Channel


Barrel EMC L1 Input - Low Eta Sum
Entries 0
Low Eta Sum - Simulated
BC101
BC102
BC103
BC104
BC105
BC106
DSM Input Channel


Barrel EMC L1 Input - High Eta Sum
Entries 7020036
High Eta Sum
BC101
BC102
BC103
BC104
BC105
BC106
DSM Input Channel


Barrel EMC L1 Input - High Eta Sum
Entries 23030
High Eta Sum - Simulated
BC101
BC102
BC103
BC104
BC105
BC106
DSM Input Channel


Barrel EMC L1 Input - High Tower Bits
Entries 7020036
High Tower Bits
BC101
BC102
BC103
BC104
BC105
BC106
DSM Input Channel


Barrel EMC L1 Input - High Tower Bits
Entries 0
High Tower Bits - Simulated
BC101
BC102
BC103
BC104
BC105
BC106
DSM Input Channel


Endcap EMC L1 Input - Low Eta Sum
Entries 2340012
Low Eta Sum
EE101
EE102
EE001 EE002-LO EE002-HI EE003 EE004 EE005-LO EE005-HI EE006 EE007 EE008-LO EE008-HI EE009


Endcap EMC L1 Input - Low Eta Sum
Entries 0
Low Eta Sum - Simulated
EE101
EE102
EE001 EE002-LO EE002-HI EE003 EE004 EE005-LO EE005-HI EE006 EE007 EE008-LO EE008-HI EE009


Endcap EMC L1 Input - High Eta Sum
Entries 2340012
High Eta Sum
EE101
EE102
EE001 EE002-LO EE002-HI EE003 EE004 EE005-LO EE005-HI EE006 EE007 EE008-LO EE008-HI EE009


Endcap EMC L1 Input - High Eta Sum
Entries 0
High Eta Sum - Simulated
EE101
EE102
EE001 EE002-LO EE002-HI EE003 EE004 EE005-LO EE005-HI EE006 EE007 EE008-LO EE008-HI EE009


Endcap EMC L1 Input - High Tower Bits
Entries 2340012
High Tower Bits
EE101
EE102
EE001 EE002-LO EE002-HI EE003 EE004 EE005-LO EE005-HI EE006 EE007 EE008-LO EE008-HI EE009


Endcap EMC L1 Input - High Tower Bits
Entries 0
High Tower Bits - Simulated
EE101
EE102
EE001 EE002-LO EE002-HI EE003 EE004 EE005-LO EE005-HI EE006 EE007 EE008-LO EE008-HI EE009


EMC L2 Input - JPX/JPA bits
Entries 1560008
JPX/JPA bits
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102
111578 111546 111310 121218 108888 108842 195001 195001
15192 15307 14987 18802 15477 15213
7910 7883 7766 11096 7947 7834
59921 60265 60938 43885 62889 65012


EMC L2 Input - JPX/JPA bits
Entries 0
JPX/JPA bits - Simulated
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - JPY/JPB bits
Entries 1560008
JPY/JPB bits
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102
110992 109709 109706 112444 108886 109349 195001 195001
15047 15452 14814 15796 15236 15628
7841 7816 7479 8352 7938 8076
61121 62924 63002 58409 62941 61948


EMC L2 Input - JPY/JPB bits
Entries 0
JPY/JPB bits - Simulated
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - JPZ/JPC bits
Entries 1560008
JPZ/JPC bits
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102
108992 106766 109751 109018 109739 109425 195001 195001
14984 15323 15165 14816 15048 15297
7701 7726 7888 7822 8021 7905
62864 65186 62187 63245 62193 63374


EMC L2 Input - JPZ/JPC bits
Entries 0
JPZ/JPC bits - Simulated
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - Partial JP Sum
Entries 1560008
Partial JP Sum
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - Partial JP Sum
Entries 0
Partial JP Sum - Simulated
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - HT01 bits/Partial JP ID
Entries 1560008
HT01 bits/Partial JP ID
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - HT01 bits/Partial JP ID
Entries 0
HT01 bits/Partial JP ID - Simulated
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - HT23 bits
Entries 1560008
HT23 bits
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - HT23 bits
Entries 0
HT23 bits - Simulated
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


BunchId7Bit (BHT3)
Entries 3427
1
10
0
20
40
60
80
100
120


BunchId7Bit (all events)
Entries 195001
10
10^2
10^3
0
20
40
60
80
100
120


BunchId7Bit (JP1)
Entries 195001
10
10^2
10^3
0
20
40
60
80
100
120


BunchId7Bit (JP2||AJP)
Entries 195001
10
10^2
10^3
0
20
40
60
80
100
120


Barrel EMC L0 Input - High Tower
Entries 5.85003e+07
High Tower
Trigger Patch
0
10
20
30
40
50
60
0
50
100
150
200
250
300
1
10
10^2
10^3
10^4
10^5


Barrel EMC L0 Input - Patch Sum
Entries 5.85003e+07
Patch Sum
Trigger Patch
0
10
20
30
40
50
60
0
50
100
150
200
250
300
1
10
10^2
10^3
10^4
10^5


Endcap EMC L0 Input - High Tower
Entries 1.755009e+07
High Tower
Trigger Patch
crate 3
crate 4
crate 5
crate 6
crate 1
crate 2


Endcap EMC L0 Input - Patch Sum
Entries 1.755009e+07
Patch Sum
Trigger Patch
crate 3
crate 4
crate 5
crate 6
crate 1
crate 2


Barrel Jet Patches
Entries 3510018
JP ADC
JP ID


Hybrid Jet Patches
Entries 390002
JP ADC
JP ID


MIX-TF001
Entries 8190042
TOF MULT
TOF tray


MIX-TF002
Entries 8190042
TOF MULT
TOF tray


MIX-TF003
Entries 8190042
TOF MULT
TOF tray


MIX-TF004
Entries 8190042
TOF MULT
TOF tray


MIX-TF005
Entries 8190042
TOF MULT
TOF tray


MIX-TF006
Entries 8190042
TOF MULT
TOF tray


MIX-TF101
Entries 1170006
TOF MULT
50
45
40
35
30
25
20
15
10
5
0
TF001
TF002
TF003
TF004
TF005
TF006
DSM Input Channel
10^4


L1-TF201
Entries 195001
10^4
10^3
0
10
20
30
40
50
60
70
80
90
100
TOF total mult


L1-TF201
Entries 1170006
Threshold bits
1
0
183362
183001
180771
182245
181423
182296
11639
12000
14230
12756
13578
12705
TF001
TF002
TF003
TF004
TF005
TF006
TOF sector
10^5


BBQ-BB001 (BBC east small tiles ADC)
Entries 3120016
ADC
QT Input Channel


BBQ-BB001 (BBC east small tiles TAC)
Entries 3120016
TAC
QT Input Channel


BBQ-BB002 (BBC west small tiles ADC)
Entries 3120016
ADC
QT Input Channel


BBQ-BB002 (BBC west small tiles TAC)
Entries 3120016
TAC
QT Input Channel


BBQ-BB003 (BBC E+W large tiles ADC)
Entries 3120016
ADC
QT Input Channel


BBQ-BB003 (BBC E+W large tiles TAC)
Entries 3120016
TAC
QT Input Channel


BBQ-ZD001 (ZDC TOWER)
Entries 3120016
ADC


BBQ-ZD001 (ZDC TOWER)
Entries 3120016
TAC


BBQ-VP001 (LO threshold)
Entries 3120016
ADC
QT Input Channel


BBQ-VP001 (LO threshold)
Entries 3120016
TAC
QT Input Channel


BBQ-VP002 (LO threshold)
Entries 3120016
ADC
QT Input Channel


BBQ-VP002 (LO threshold)
Entries 3120016
TAC
QT Input Channel


BBQ-VP003 (HI threshold)
Entries 3120016
ADC
QT Input Channel


BBQ-VP003 (HI threshold)
Entries 3120016
TAC
QT Input Channel


BBQ-VP004 (HI threshold)
Entries 3120016
ADC
QT Input Channel


BBQ-VP004 (HI threshold)
Entries 3120016
TAC
QT Input Channel


Entries 195001
TOF Mult
BBC-L-East ADC Sum


Entries 195001
TOF Mult
BBC-L-West ADC Sum


Entries 195001
TOF Mult
BBC-S-East ADC Sum


Entries 195001
TOF Mult
BBC-S-West ADC Sum


Entries 195001
TOF Mult
ZDC-East ADC Sum Att


Entries 195001
TOF Mult
ZDC-West ADC Sum Att


Entries 195001
BBC-L-East ADC Sum
BBC-S-East ADC Sum


Entries 195001
BBC-L-West ADC Sum
BBC-S-West ADC Sum


Entries 195001
BBC-L-East ADC Sum
ZDC-East ADC Sum Att


Entries 195001
BBC-L-West ADC Sum
ZDC-West ADC Sum Att


Entries 195001
BBC-S-East ADC Sum
ZDC-East ADC Sum Att


Entries 195001
BBC-S-West ADC Sum
ZDC-West ADC Sum Att


Entries 195001
BBC-L-East ADC Sum
BBC-L-West ADC Sum


Entries 195001
BBC-S-East ADC Sum
BBC-S-West ADC Sum


Entries 195001
ZDC East ADC Sum Att
ZDC West ADC Sum Att


Entries 195001
BBC-L TAC Diff
BCC-S TAC Diff
Entries 195001
BBC-L TAC Diff
VPD TAC Diff
Entries 195001
BBC-L TAC Diff
ZDC TAC Diff
Entries 195001
BBC-S TAC Diff
VPD TAC Diff
Entries 195001
BBC-S TAC Diff
ZDC TAC Diff
Entries 195001
VPD TAC Diff
ZDC TAC Diff


Input to QT1 crate
Entries 0
ADC
1000
800
600
400
200
0
0 50 100 150 200 250 300 350
channel


Input to QT2 crate
Entries 0
ADC
1000
800
600
400
200
0
0 50 100 150 200 250 300 350
channel


Input to QT3 crate
Entries 0
ADC
1000
800
600
400
200
0
0 50 100 150 200 250 300 350
channel


Input to QT4 crate
Entries 0
ADC
1000
800
600
400
200
0
0 50 100 150 200 250 300 350
channel


Input to FMS L0 DSM
Entries 9360048
QT8(0) sum
QT board


Input to FMS L0 DSM
Entries 1560008
QT8(0) sum - simulated
QT board


Input to FMS L0 DSM
Entries 9360048
QT8(1) sum
QT board


Input to FMS L0 DSM
Entries 1560008
QT8(1) sum - simulated
QT board


Input to FMS L0 DSM
Entries 9360048
QT8(2) sum
QT board


Input to FMS L0 DSM
Entries 1560008
QT8(2) sum - simulated
QT board


Input to FMS L0 DSM
Entries 9360048
QT8(3) sum
QT board


Input to FMS L0 DSM
Entries 1560008
QT8(3) sum - simulated
QT board


Input to FMS L0 DSM
Entries 9360048
HT ADC
QT board


Input to FMS L0 DSM
Entries 1560008
HT ADC - simulated
QT board


Input to FMS L0 DSM
Entries 9360048
HT ID
QT board


Input to FMS L0 DSM
Entries 1560008
HT ID - simulated
QT board


Input to FMS L1 DSM
Entries 2340012
sumD
DSM board


Input to FMS L1 DSM
Entries 0
sumD - simulated
DSM board


Input to FMS L1 DSM
Entries 2340012
sumC
DSM board


Input to FMS L1 DSM
Entries 0
sumC - simulated
DSM board


Input to FMS L1 DSM
Entries 2340012
sumBC
DSM board


Input to FMS L1 DSM
Entries 0
sumBC - simulated
DSM board


Input to FMS L1 DSM
Entries 2340012
sumB
DSM board


Input to FMS L1 DSM
Entries 0
sumB - simulated
DSM board


Input to FMS L1 DSM
Entries 2340012
sumAB
DSM board


Input to FMS L1 DSM
Entries 0
sumAB - simulated
DSM board


Input to FMS L1 DSM
Entries 2340012
sumA
DSM board


Input to FMS L1 DSM
Entries 0
sumA - simulated
DSM board


Input to FMS L1 DSM
Entries 2340012
FMS L1 HT bits
DSM board


Input to FMS L1 DSM
Entries 0
FMS L1 HT bits - simulated
DSM board


Input to FPD L2 DSM
Entries 1560008
quadrant sum
SMALL-ST
SMALL-SB
SMALL-NT
SMALL-NB
LARGE-ST
LARGE-SB
LARGE-NT
LARGE-NB


Input to FPD L2 DSM
Entries 1560008
quadrant sum - simulated
SMALL-ST
SMALL-SB
SMALL-NT
SMALL-NB
LARGE-ST
LARGE-SB
LARGE-NT
LARGE-NB


Input to FPD L2 DSM
Entries 585003
CL bits
195000
195001
195001
1
SMALL
LARGE-S
LARGE-N


Input to FPD L2 DSM
Entries 585003
CL bits - simulated
195000
195001
195001
1
SMALL
LARGE-S
LARGE-N


Input to FPD L2 DSM
Entries 585003
HT bits
195000
195001
194999
1
2
SMALL
LARGE-S
LARGE-N


Input to FPD L2 DSM
Entries 585003
HT bits - simulated
195000
195001
194999
1
2
SMALL
LARGE-S
LARGE-N


Input to FPD L2 DSM
Entries 780004
jet patch sum (no FMS-LED)
0
20
40
60
80
100
120
ST
SB
NT
NB
1
10
10^2
10^3
10^4
10^5


Input to FE001 QT board
Entries6240032
ADC
channel


Input to FE002 QT board
Entries6240032
ADC
channel


Input to FE003 QT board
Entries6240032
ADC
channel


Input to FE004 QT board
Entries6240032
ADC
channel


TF201 0-15 (ch0)
Entries 3120016
MTD ET ITE ITW TOFmult0 TOFmult1 TOFmult2 TOFmult3 TOFmult4 TOFsector0 TOFsector1 TOFsector2 TOFsector3 TOFsector4 TOFsector5 MTD-Cosmic


TF201 0-15 (ch0)
Entries 0
MTD ET ITE ITW TOFmult0 TOFmult1 TOFmult2 TOFmult3 TOFmult4 TOFsector0 TOFsector1 TOFsector2 TOFsector3 TOFsector4 TOFsector5 MTD-Cosmic


VT201 0-15 (ch1)
Entries 3120016
BBC-TAC BBC-E BBC-W BBC-L-TAC BBC-L-E BBC-L-W ZDC-TAC ZDC-E ZDC-W ZDC-E-Front ZDC-E-Back ZDC-W-Front ZDC-W-Back VPD-TAC VPD-E VPD-W


VT201 0-15 (ch1)
Entries 615237
BBC-TAC BBC-E BBC-W BBC-L-TAC BBC-L-E BBC-L-W ZDC-TAC ZDC-E ZDC-W ZDC-E-Front ZDC-E-Back ZDC-W-Front ZDC-W-Back VPD-TAC VPD-E VPD-W


Unused (ch2)
Entries 3120016


Entries 0


EM201 0-15 (ch3)
Entries 3120016
BHT0 BHT1 BHT2 BHT3 EHT2 EHT4 JP1 JP2 BJP1 BJP2 EJP1 EJP2 AJP BAJP EAJP JP0


EM201 0-15 (ch3)
Entries 1016
BHT0 BHT1 BHT2 BHT3 EHT2 EHT4 JP1 JP2 BJP1 BJP2 EJP1 EJP2 AJP BAJP EAJP JP0

RAT board (ch4)





FP201 0-15 (ch5)



FP201 0-15 (ch5)



ST201 0-15 (ch6)





Unused (ch7)






FP201 Channel 0 Bit Errors
Entries3120016
Number of Errors
Bit


FP201 Channel 1 Bit Errors
Entries3104049
Number of Errors
Bit


FP201 Channel 2 Bit Errors
Entries3120016
Number of Errors
Bit


FP201 Channel 3 Bit Errors
Entries3120009
Number of Errors
Bit


FP201 Channel 4 Bit Errors
Entries3120016
Number of Errors
Bit


FP201 Channel 5 Bit Errors
Entries3120014
Number of Errors
Bit


FP201 Channel 6 Bit Errors
Entries 92917
Number of Errors
Bit


FP201 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM006 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM006 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM006 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM006 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM006 Channel 4 Bit Errors
Entries3120016
Number of Errors
Bit


FM006 Channel 5 Bit Errors
Entries3120016
Number of Errors
Bit


FM006 Channel 6 Bit Errors
Entries3120016
Number of Errors
Bit


FM006 Channel 7 Bit Errors
Entries3120016
Number of Errors
Bit


FM007 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM007 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM007 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM007 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM007 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM007 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM007 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM007 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM008 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM008 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM008 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM008 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM008 Channel 4 Bit Errors
Entries3120016
Number of Errors
Bit


FM008 Channel 5 Bit Errors
Entries3120016
Number of Errors
Bit


FM008 Channel 6 Bit Errors
Entries3120016
Number of Errors
Bit


FM008 Channel 7 Bit Errors
Entries3120016
Number of Errors
Bit


FM009 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM009 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM009 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM009 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM009 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM009 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM009 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM009 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM010 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM010 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM010 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM010 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM010 Channel 4 Bit Errors
Entries3120016
Number of Errors
Bit


FM010 Channel 5 Bit Errors
Entries3120016
Number of Errors
Bit


FM010 Channel 6 Bit Errors
Entries3120016
Number of Errors
Bit


FM010 Channel 7 Bit Errors
Entries3120016
Number of Errors
Bit


FM011 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM011 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM011 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM011 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM011 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM011 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM011 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM011 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM012 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM012 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM012 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM012 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM012 Channel 4 Bit Errors
Entries3120016
Number of Errors
Bit


FM012 Channel 5 Bit Errors
Entries3120016
Number of Errors
Bit


FM012 Channel 6 Bit Errors
Entries3120016
Number of Errors
Bit


FM012 Channel 7 Bit Errors
Entries3120016
Number of Errors
Bit