
Barrel EMC L1 Input - Low Eta Sum
Entries 2372256
Low Eta Sum
BC101
BC102
BC103
BC104
BC105
BC106
DSM Input Channel


Barrel EMC L1 Input - Low Eta Sum
Entries 0
Low Eta Sum - Simulated
BC101
BC102
BC103
BC104
BC105
BC106
DSM Input Channel


Barrel EMC L1 Input - High Eta Sum
Entries 2372256
High Eta Sum
BC101
BC102
BC103
BC104
BC105
BC106
DSM Input Channel


Barrel EMC L1 Input - High Eta Sum
Entries 29705
High Eta Sum - Simulated
BC101
BC102
BC103
BC104
BC105
BC106
DSM Input Channel


Barrel EMC L1 Input - High Tower Bits
Entries 2372256
High Tower Bits
BC101
BC102
BC103
BC104
BC105
BC106
DSM Input Channel


Barrel EMC L1 Input - High Tower Bits
Entries 0
High Tower Bits - Simulated
BC101
BC102
BC103
BC104
BC105
BC106
DSM Input Channel


Endcap EMC L1 Input - Low Eta Sum
Entries 790752
Low Eta Sum
EE101
EE102
EE001 EE002-LO EE002-HI EE003 EE004 EE005-LO EE005-HI EE006 EE007 EE008-LO EE008-HI EE009


Endcap EMC L1 Input - Low Eta Sum
Entries 0
Low Eta Sum - Simulated
EE101
EE102
EE001 EE002-LO EE002-HI EE003 EE004 EE005-LO EE005-HI EE006 EE007 EE008-LO EE008-HI EE009


Endcap EMC L1 Input - High Eta Sum
Entries 790752
High Eta Sum
EE101
EE102
EE001 EE002-LO EE002-HI EE003 EE004 EE005-LO EE005-HI EE006 EE007 EE008-LO EE008-HI EE009


Endcap EMC L1 Input - High Eta Sum
Entries 0
High Eta Sum - Simulated
EE101
EE102
EE001 EE002-LO EE002-HI EE003 EE004 EE005-LO EE005-HI EE006 EE007 EE008-LO EE008-HI EE009


Endcap EMC L1 Input - High Tower Bits
Entries 790752
High Tower Bits
EE101
EE102
EE001 EE002-LO EE002-HI EE003 EE004 EE005-LO EE005-HI EE006 EE007 EE008-LO EE008-HI EE009


Endcap EMC L1 Input - High Tower Bits
Entries 0
High Tower Bits - Simulated
EE101
EE102
EE001 EE002-LO EE002-HI EE003 EE004 EE005-LO EE005-HI EE006 EE007 EE008-LO EE008-HI EE009


EMC L2 Input - JPX/JPA bits
Entries 527168
JPX/JPA bits
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102
35265 35241 35171 38803 34133 33697 65896 65896
5691 5620 5387 7047 5607 5482
2995 2973 3038 4374 3037 2954
21945 22062 22300 15672 23119 23763


EMC L2 Input - JPX/JPA bits
Entries 0
JPX/JPA bits - Simulated
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - JPY/JPB bits
Entries 527168
JPY/JPB bits
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102
34821 34196 34328 35339 34043 34531 65896 65896
5584 5579 5430 5713 5616 5752
2940 2976 2853 3151 3038 3017
22551 23145 23285 21693 23199 22596


EMC L2 Input - JPY/JPB bits
Entries 0
JPY/JPB bits - Simulated
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - JPZ/JPC bits
Entries 527168
JPZ/JPC bits
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102
34180 33530 34098 34344 34606 34374 65896 65896
5539 5565 5608 5642 5840 5517
2897 2935 2951 2863 2998 3028
23280 23866 23239 23047 22452 22977


EMC L2 Input - JPZ/JPC bits
Entries 0
JPZ/JPC bits - Simulated
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - Partial JP Sum
Entries 527168
Partial JP Sum
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - Partial JP Sum
Entries 0
Partial JP Sum - Simulated
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - HT01 bits/Partial JP ID
Entries 527168
HT01 bits/Partial JP ID
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - HT01 bits/Partial JP ID
Entries 0
HT01 bits/Partial JP ID - Simulated
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - HT23 bits
Entries 527168
HT23 bits
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - HT23 bits
Entries 0
HT23 bits - Simulated
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


BunchId7Bit (BHT3)
Entries 587
10
1
0
20
40
60
80
100
120


BunchId7Bit (all events)
Entries 65896
10^3
10^2
10
0
20
40
60
80
100
120


BunchId7Bit (JP1)
Entries 65896
10^3
10^2
10
0
20
40
60
80
100
120


BunchId7Bit (JP2||AJP)
Entries 65896
10^3
10^2
10
0
20
40
60
80
100
120


Barrel EMC L0 Input - High Tower
Entries 1.97688e+07
High Tower
Trigger Patch
0
10
20
30
40
50
60
0
50
100
150
200
250
300
1
10
10^2
10^3
10^4


Barrel EMC L0 Input - Patch Sum
Entries 1.97688e+07
Patch Sum
Trigger Patch
0
10
20
30
40
50
60
0
50
100
150
200
250
300
1
10
10^2
10^3
10^4


Endcap EMC L0 Input - High Tower
Entries 5930640
High Tower
crate 3
crate 4
crate 5
crate 6
crate 1
crate 2
Trigger Patch


Endcap EMC L0 Input - Patch Sum
Entries 5930640
Patch Sum
crate 3
crate 4
crate 5
crate 6
crate 1
crate 2
Trigger Patch


Barrel Jet Patches
Entries 1186128
JP ADC
JP ID


Hybrid Jet Patches
Entries 131792
JP ADC
JP ID


MIX-TF001
Entries 2767632
TOF MULT
TOF tray


MIX-TF002
Entries 2767632
TOF MULT
TOF tray


MIX-TF003
Entries 2767632
TOF MULT
TOF tray


MIX-TF004
Entries 2767632
TOF MULT
TOF tray


MIX-TF005
Entries 2767632
TOF MULT
TOF tray


MIX-TF006
Entries 2767632
TOF MULT
TOF tray


MIX-TF101
Entries 395376
TOF MULT
50
45
40
35
30
25
20
15
10
5
0
TF001
TF002
TF003
TF004
TF005
TF006
DSM Input Channel
10^3


L1-TF201
Entries 65896
10^3
10^2
0
10
20
30
40
50
60
70
80
90
100
TOF total mult


L1-TF201
Entries 395376
Threshold bits
1
0
63118
62942
61645
63023
62992
62979
2778
2954
4251
2873
2904
2917
TF001
TF002
TF003
TF004
TF005
TF006
TOF sector
10^4


BBQ-BB001 (BBC east small tiles ADC)
Entries 1054336
ADC
QT Input Channel


BBQ-BB001 (BBC east small tiles TAC)
Entries 1054336
TAC
QT Input Channel


BBQ-BB002 (BBC west small tiles ADC)
Entries 1054336
ADC
QT Input Channel


BBQ-BB002 (BBC west small tiles TAC)
Entries 1054336
TAC
QT Input Channel


BBQ-BB003 (BBC E+W large tiles ADC)
Entries 1054336
ADC
QT Input Channel


BBQ-BB003 (BBC E+W large tiles TAC)
Entries 1054336
TAC
QT Input Channel


BBQ-ZD001 (ZDC TOWER)
Entries 1054336
ADC


BBQ-ZD001 (ZDC TOWER)
Entries 1054336
TAC


BBQ-VP001 (LO threshold)
Entries 1054336
ADC
QT Input Channel


BBQ-VP001 (LO threshold)
Entries 1054336
TAC
QT Input Channel


BBQ-VP002 (LO threshold)
Entries 1054336
ADC
QT Input Channel


BBQ-VP002 (LO threshold)
Entries 1054336
TAC
QT Input Channel


BBQ-VP003 (HI threshold)
Entries 1054336
ADC
QT Input Channel


BBQ-VP003 (HI threshold)
Entries 1054336
TAC
QT Input Channel


BBQ-VP004 (HI threshold)
Entries 1054336
ADC
QT Input Channel


BBQ-VP004 (HI threshold)
Entries 1054336
TAC
QT Input Channel


Entries 65896
TOF Mult
BBC-L-East ADC Sum


Entries 65896
TOF Mult
BBC-L-West ADC Sum


Entries 65896
TOF Mult
BBC-S-East ADC Sum


Entries 65896
TOF Mult
BBC-S-West ADC Sum


Entries 65896
TOF Mult
ZDC-East ADC Sum Att


Entries 65896
TOF Mult
ZDC-West ADC Sum Att


Entries 65896
BBC-L-East ADC Sum
BBC-S-East ADC Sum


Entries 65896
BBC-L-West ADC Sum
BBC-S-West ADC Sum


Entries 65896
BBC-L-East ADC Sum
ZDC-East ADC Sum Att


Entries 65896
BBC-L-West ADC Sum
ZDC-West ADC Sum Att


Entries 65896
BBC-S-East ADC Sum
ZDC-East ADC Sum Att


Entries 65896
BBC-S-West ADC Sum
ZDC-West ADC Sum Att


Entries 65896
BBC-L-East ADC Sum
BBC-L-West ADC Sum


Entries 65896
BBC-S-East ADC Sum
BBC-S-West ADC Sum


Entries 65896
ZDC East ADC Sum Att
ZDC West ADC Sum Att


Entries 65896
BBC-L TAC Diff
BCC-S TAC Diff
Entries 65896
BBC-L TAC Diff
VPD TAC Diff
Entries 65896
BBC-L TAC Diff
ZDC TAC Diff
Entries 65896
BBC-S TAC Diff
VPD TAC Diff
Entries 65896
BBC-S TAC Diff
ZDC TAC Diff
Entries 65896
VPD TAC Diff
ZDC TAC Diff


Input to QT1 crate
Entries 0
ADC
1000
800
600
400
200
0
0 50 100 150 200 250 300 350
channel


Input to QT2 crate
Entries 0
ADC
1000
800
600
400
200
0
0 50 100 150 200 250 300 350
channel


Input to QT3 crate
Entries 0
ADC
1000
800
600
400
200
0
0 50 100 150 200 250 300 350
channel


Input to QT4 crate
Entries 0
ADC
1000
800
600
400
200
0
0 50 100 150 200 250 300 350
channel


Input to FMS L0 DSM
Entries 3163008
QT8(0) sum
QT board


Input to FMS L0 DSM
Entries 527168
QT8(0) sum - simulated
QT board


Input to FMS L0 DSM
Entries 3163008
QT8(1) sum
QT board


Input to FMS L0 DSM
Entries 527168
QT8(1) sum - simulated
QT board


Input to FMS L0 DSM
Entries 3163008
QT8(2) sum
QT board


Input to FMS L0 DSM
Entries 527168
QT8(2) sum - simulated
QT board


Input to FMS L0 DSM
Entries 3163008
QT8(3) sum
QT board


Input to FMS L0 DSM
Entries 527168
QT8(3) sum - simulated
QT board


Input to FMS L0 DSM
Entries 3163008
HT ADC
QT board


Input to FMS L0 DSM
Entries 527168
HT ADC - simulated
QT board


Input to FMS L0 DSM
Entries 3163008
HT ID
QT board


Input to FMS L0 DSM
Entries 527168
HT ID - simulated
QT board


Input to FMS L1 DSM
Entries 790752
sumD
DSM board


Input to FMS L1 DSM
Entries 0
sumD - simulated
DSM board


Input to FMS L1 DSM
Entries 790752
sumC
DSM board


Input to FMS L1 DSM
Entries 0
sumC - simulated
DSM board


Input to FMS L1 DSM
Entries 790752
sumBC
DSM board


Input to FMS L1 DSM
Entries 0
sumBC - simulated
DSM board


Input to FMS L1 DSM
Entries 790752
sumB
DSM board


Input to FMS L1 DSM
Entries 0
sumB - simulated
DSM board


Input to FMS L1 DSM
Entries 790752
sumAB
DSM board


Input to FMS L1 DSM
Entries 0
sumAB - simulated
DSM board


Input to FMS L1 DSM
Entries 790752
sumA
DSM board


Input to FMS L1 DSM
Entries 0
sumA - simulated
DSM board


Input to FMS L1 DSM
Entries 790752
FMS L1 HT bits
DSM board


Input to FMS L1 DSM
Entries 0
FMS L1 HT bits - simulated
DSM board


Input to FPD L2 DSM
Entries 527168
quadrant sum
SMALL-ST
SMALL-SB
SMALL-NT
SMALL-NB
LARGE-ST
LARGE-SB
LARGE-NT
LARGE-NB


Input to FPD L2 DSM
Entries 527168
quadrant sum - simulated
SMALL-ST
SMALL-SB
SMALL-NT
SMALL-NB
LARGE-ST
LARGE-SB
LARGE-NT
LARGE-NB


Input to FPD L2 DSM
Entries 197688
CL bits
65896
SMALL
LARGE-S
LARGE-N


Input to FPD L2 DSM
Entries 197688
CL bits - simulated
65896
SMALL
LARGE-S
LARGE-N


Input to FPD L2 DSM
Entries 197688
HT bits
65896
SMALL
LARGE-S
LARGE-N


Input to FPD L2 DSM
Entries 197688
HT bits - simulated
65896
SMALL
LARGE-S
LARGE-N


Input to FPD L2 DSM
Entries 263584
jet patch sum (no FMS-LED)
0
20
40
60
80
100
120
ST
SB
NT
NB
1
10
10^2
10^3
10^4


Input to FE001 QT board
Entries2108672
ADC
channel


Input to FE002 QT board
Entries2108672
ADC
channel


Input to FE003 QT board
Entries2108672
ADC
channel


Input to FE004 QT board
Entries2108672
ADC
channel


TF201 0-15 (ch0)
Entries 1054336
MTD ET ITE ITW TOFmult0 TOFmult1 TOFmult2 TOFmult3 TOFmult4 TOFsector0 TOFsector1 TOFsector2 TOFsector3 TOFsector4 TOFsector5 MTD-Cosmic


TF201 0-15 (ch0)
Entries 0
MTD ET ITE ITW TOFmult0 TOFmult1 TOFmult2 TOFmult3 TOFmult4 TOFsector0 TOFsector1 TOFsector2 TOFsector3 TOFsector4 TOFsector5 MTD-Cosmic


VT201 0-15 (ch1)
Entries 1054336
BBC-TAC BBC-E BBC-W BBC-L-TAC BBC-L-E BBC-L-W ZDC-TAC ZDC-E ZDC-W ZDC-E-Front ZDC-E-Back ZDC-W-Front ZDC-W-Back VPD-TAC VPD-E VPD-W


VT201 0-15 (ch1)
Entries 207072
BBC-TAC BBC-E BBC-W BBC-L-TAC BBC-L-E BBC-L-W ZDC-TAC ZDC-E ZDC-W ZDC-E-Front ZDC-E-Back ZDC-W-Front ZDC-W-Back VPD-TAC VPD-E VPD-W


Unused (ch2)
Entries 1054336


Entries 0


EM201 0-15 (ch3)
Entries 1054336
BHT0 BHT1 BHT2 BHT3 EHT2 EHT4 JP1 JP2 BJP1 BJP2 EJP1 EJP2 AJP BAJP EAJP JP0


EM201 0-15 (ch3)
Entries 221
BHT0 BHT1 BHT2 BHT3 EHT2 EHT4 JP1 JP2 BJP1 BJP2 EJP1 EJP2 AJP BAJP EAJP JP0

RAT board (ch4)





FP201 0-15 (ch5)



FP201 0-15 (ch5)



ST201 0-15 (ch6)





Unused (ch7)






FP201 Channel 0 Bit Errors
Entries1054336
Number of Errors
×10³
Bit


FP201 Channel 1 Bit Errors
Entries1046536
Number of Errors
Bit


FP201 Channel 2 Bit Errors
Entries1054336
Number of Errors
×10³
Bit


FP201 Channel 3 Bit Errors
Entries1054334
Number of Errors
Bit


FP201 Channel 4 Bit Errors
Entries1054336
Number of Errors
×10³
Bit


FP201 Channel 5 Bit Errors
Entries1054336
Number of Errors
×10³
Bit


FP201 Channel 6 Bit Errors
Entries 31125
Number of Errors
Bit


FP201 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM006 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM006 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM006 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM006 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM006 Channel 4 Bit Errors
Entries1054336
Number of Errors
Bit


FM006 Channel 5 Bit Errors
Entries1054336
Number of Errors
Bit


FM006 Channel 6 Bit Errors
Entries1054336
Number of Errors
Bit


FM006 Channel 7 Bit Errors
Entries1054336
Number of Errors
Bit


FM007 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM007 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM007 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM007 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM007 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM007 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM007 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM007 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM008 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM008 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM008 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM008 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM008 Channel 4 Bit Errors
Entries1054336
Number of Errors
Bit


FM008 Channel 5 Bit Errors
Entries1054336
Number of Errors
Bit


FM008 Channel 6 Bit Errors
Entries1054336
Number of Errors
Bit


FM008 Channel 7 Bit Errors
Entries1054336
Number of Errors
Bit


FM009 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM009 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM009 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM009 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM009 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM009 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM009 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM009 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM010 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM010 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM010 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM010 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM010 Channel 4 Bit Errors
Entries1054336
Number of Errors
Bit


FM010 Channel 5 Bit Errors
Entries1054336
Number of Errors
Bit


FM010 Channel 6 Bit Errors
Entries1054336
Number of Errors
Bit


FM010 Channel 7 Bit Errors
Entries1054336
Number of Errors
Bit


FM011 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM011 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM011 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM011 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM011 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM011 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM011 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM011 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM012 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM012 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM012 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM012 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM012 Channel 4 Bit Errors
Entries1054336
Number of Errors
Bit


FM012 Channel 5 Bit Errors
Entries1054336
Number of Errors
Bit


FM012 Channel 6 Bit Errors
Entries1054336
Number of Errors
Bit


FM012 Channel 7 Bit Errors
Entries1054336
Number of Errors
Bit