
Barrel EMC L1 Input - Low Eta Sum
Entries 428868
Low Eta Sum
BC101
BC102
BC103
BC104
BC105
BC106
DSM Input Channel


Barrel EMC L1 Input - Low Eta Sum
Entries 0
Low Eta Sum - Simulated
BC101
BC102
BC103
BC104
BC105
BC106
DSM Input Channel


Barrel EMC L1 Input - High Eta Sum
Entries 428868
High Eta Sum
BC101
BC102
BC103
BC104
BC105
BC106
DSM Input Channel


Barrel EMC L1 Input - High Eta Sum
Entries 0
High Eta Sum - Simulated
BC101
BC102
BC103
BC104
BC105
BC106
DSM Input Channel


Barrel EMC L1 Input - High Tower Bits
Entries 428868
High Tower Bits
BC101
BC102
BC103
BC104
BC105
BC106
DSM Input Channel


Barrel EMC L1 Input - High Tower Bits
Entries 0
High Tower Bits - Simulated
BC101
BC102
BC103
BC104
BC105
BC106
DSM Input Channel


Endcap EMC L1 Input - Low Eta Sum
Entries 142956
Low Eta Sum
EE101
EE102
EE001 EE002-LO EE002-HI EE003 EE004 EE005-LO EE005-HI EE006 EE007 EE008-LO EE008-HI EE009


Endcap EMC L1 Input - Low Eta Sum
Entries 0
Low Eta Sum - Simulated
EE101
EE102
EE001 EE002-LO EE002-HI EE003 EE004 EE005-LO EE005-HI EE006 EE007 EE008-LO EE008-HI EE009


Endcap EMC L1 Input - High Eta Sum
Entries 142956
High Eta Sum
EE101
EE102
EE001 EE002-LO EE002-HI EE003 EE004 EE005-LO EE005-HI EE006 EE007 EE008-LO EE008-HI EE009


Endcap EMC L1 Input - High Eta Sum
Entries 0
High Eta Sum - Simulated
EE101
EE102
EE001 EE002-LO EE002-HI EE003 EE004 EE005-LO EE005-HI EE006 EE007 EE008-LO EE008-HI EE009


Endcap EMC L1 Input - High Tower Bits
Entries 142956
High Tower Bits
EE101
EE102
EE001 EE002-LO EE002-HI EE003 EE004 EE005-LO EE005-HI EE006 EE007 EE008-LO EE008-HI EE009


Endcap EMC L1 Input - High Tower Bits
Entries 0
High Tower Bits - Simulated
EE101
EE102
EE001 EE002-LO EE002-HI EE003 EE004 EE005-LO EE005-HI EE006 EE007 EE008-LO EE008-HI EE009


EMC L2 Input - JPX/JPA bits
Entries 95304
JPX/JPA bits
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102
7084 7023 6990 11883 6873 6787 11913 11913
878 888 884 30 893 900
470 488 445 471 465
3481 3514 3594 3676 3761


EMC L2 Input - JPX/JPA bits
Entries 0
JPX/JPA bits - Simulated
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - JPY/JPB bits
Entries 95304
JPY/JPB bits
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102
6981 6853 6908 11376 6845 6959 11913 11913
900 902 894 537 904 904
469 459 430 502 469
3563 3699 3681 3662 3581


EMC L2 Input - JPY/JPB bits
Entries 0
JPY/JPB bits - Simulated
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - JPZ/JPC bits
Entries 95304
JPZ/JPC bits
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102
6878 6770 6850 6887 6920 6932 11913 11913
880 885 904 871 894 895
501 449 485 452 455 451
3654 3809 3574 3703 3644 3635


EMC L2 Input - JPZ/JPC bits
Entries 0
JPZ/JPC bits - Simulated
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - Partial JP Sum
Entries 95304
Partial JP Sum
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - Partial JP Sum
Entries 0
Partial JP Sum - Simulated
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - HT01 bits/Partial JP ID
Entries 95304
HT01 bits/Partial JP ID
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - HT01 bits/Partial JP ID
Entries 0
HT01 bits/Partial JP ID - Simulated
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - HT23 bits
Entries 95304
HT23 bits
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


EMC L2 Input - HT23 bits
Entries 0
HT23 bits - Simulated
DSM Input Channel
BC101 BC102 BC103 BC104 BC105 BC106 EE101 EE102


BunchId7Bit (BHT3)
Entries 348
10
1
0
20
40
60
80
100
120


BunchId7Bit (all events)
Entries 11913
10^2
10
1
0
20
40
60
80
100
120


BunchId7Bit (JP1)
Entries 11913
10^2
10
1
0
20
40
60
80
100
120


BunchId7Bit (JP2||AJP)
Entries 11913
10^2
10
1
0
20
40
60
80
100
120


Barrel EMC L0 Input - High Tower
Entries 3573900
High Tower
Trigger Patch
0
10
20
30
40
50
60
0
50
100
150
200
250
300
1
10
10^2
10^3
10^4


Barrel EMC L0 Input - Patch Sum
Entries 3573900
Patch Sum
Trigger Patch
0
10
20
30
40
50
60
0
50
100
150
200
250
300
1
10
10^2
10^3
10^4


Endcap EMC L0 Input - High Tower
Entries 1072170
High Tower
crate 3
crate 4
crate 5
crate 6
crate 1
crate 2
Trigger Patch


Endcap EMC L0 Input - Patch Sum
Entries 1072170
Patch Sum
crate 3
crate 4
crate 5
crate 6
crate 1
crate 2
Trigger Patch


Barrel Jet Patches
Entries 214434
JP ADC
JP ID


Hybrid Jet Patches
Entries 23826
JP ADC
JP ID


MIX-TF001
Entries 500346
TOF MULT
TOF tray


MIX-TF002
Entries 500346
TOF MULT
TOF tray


MIX-TF003
Entries 500346
TOF MULT
TOF tray


MIX-TF004
Entries 500346
TOF MULT
TOF tray


MIX-TF005
Entries 500346
TOF MULT
TOF tray


MIX-TF006
Entries 500346
TOF MULT
TOF tray


MIX-TF101
Entries 71478
TOF MULT
50
45
40
35
30
25
20
15
10
5
0
TF001
TF002
TF003
TF004
TF005
TF006
DSM Input Channel
10^2
10
1


L1-TF201
Entries 11913
10^2
10
0
10
20
30
40
50
60
70
80
90
100
TOF total mult


L1-TF201
Entries 71478
Threshold bits
1
0
11310
11275
11057
11286
11913
11243
603
638
856
627
670
TF001
TF002
TF003
TF004
TF005
TF006
TOF sector
10^4
10^3
10^2
10
1


BBQ-BB001 (BBC east small tiles ADC)
Entries 190608
ADC
QT Input Channel


BBQ-BB001 (BBC east small tiles TAC)
Entries 190608
TAC
QT Input Channel


BBQ-BB002 (BBC west small tiles ADC)
Entries 190608
ADC
QT Input Channel


BBQ-BB002 (BBC west small tiles TAC)
Entries 190608
TAC
QT Input Channel


BBQ-BB003 (BBC E+W large tiles ADC)
Entries 190608
ADC
QT Input Channel


BBQ-BB003 (BBC E+W large tiles TAC)
Entries 190608
TAC
QT Input Channel


BBQ-ZD001 (ZDC TOWER)
Entries 190608
ADC


BBQ-ZD001 (ZDC TOWER)
Entries 190608
TAC


BBQ-VP001 (LO threshold)
Entries 190608
ADC
QT Input Channel


BBQ-VP001 (LO threshold)
Entries 190608
TAC
QT Input Channel


BBQ-VP002 (LO threshold)
Entries 190608
ADC
QT Input Channel


BBQ-VP002 (LO threshold)
Entries 190608
TAC
QT Input Channel


BBQ-VP003 (HI threshold)
Entries 190608
ADC
QT Input Channel


BBQ-VP003 (HI threshold)
Entries 190608
TAC
QT Input Channel


BBQ-VP004 (HI threshold)
Entries 190608
ADC
QT Input Channel


BBQ-VP004 (HI threshold)
Entries 190608
TAC
QT Input Channel


Entries 11913
TOF Mult
BBC-L-East ADC Sum


Entries 11913
TOF Mult
BBC-L-West ADC Sum


Entries 11913
TOF Mult
BBC-S-East ADC Sum


Entries 11913
TOF Mult
BBC-S-West ADC Sum


Entries 11913
TOF Mult
ZDC-East ADC Sum Att


Entries 11913
TOF Mult
ZDC-West ADC Sum Att


Entries 11913
BBC-L-East ADC Sum
BBC-S-East ADC Sum


Entries 11913
BBC-L-West ADC Sum
BBC-S-West ADC Sum


Entries 11913
BBC-L-East ADC Sum
ZDC-East ADC Sum Att


Entries 11913
BBC-L-West ADC Sum
ZDC-West ADC Sum Att


Entries 11913
BBC-S-East ADC Sum
ZDC-East ADC Sum Att


Entries 11913
BBC-S-West ADC Sum
ZDC-West ADC Sum Att


Entries 11913
BBC-L-East ADC Sum
BBC-L-West ADC Sum


Entries 11913
BBC-S-East ADC Sum
BBC-S-West ADC Sum


Entries 11913
ZDC East ADC Sum Att
ZDC West ADC Sum Att


Entries 11913
BBC-L TAC Diff
BCC-S TAC Diff
Entries 11913
BBC-L TAC Diff
VPD TAC Diff
Entries 11913
BBC-L TAC Diff
ZDC TAC Diff
Entries 11913
BBC-S TAC Diff
VPD TAC Diff
Entries 11913
BBC-S TAC Diff
ZDC TAC Diff
Entries 11913
VPD TAC Diff
ZDC TAC Diff


Input to QT1 crate
Entries 0
ADC
1000
800
600
400
200
0
0 50 100 150 200 250 300 350
channel


Input to QT2 crate
Entries 0
ADC
1000
800
600
400
200
0
0 50 100 150 200 250 300 350
channel


Input to QT3 crate
Entries 0
ADC
1000
800
600
400
200
0
0 50 100 150 200 250 300 350
channel


Input to QT4 crate
Entries 0
ADC
1000
800
600
400
200
0
0 50 100 150 200 250 300 350
channel


Input to FMS L0 DSM
Entries 571824
QT8(0) sum
QT board


Input to FMS L0 DSM
Entries 95304
QT8(0) sum - simulated
QT board


Input to FMS L0 DSM
Entries 571824
QT8(1) sum
QT board


Input to FMS L0 DSM
Entries 95304
QT8(1) sum - simulated
QT board


Input to FMS L0 DSM
Entries 571824
QT8(2) sum
QT board


Input to FMS L0 DSM
Entries 95304
QT8(2) sum - simulated
QT board


Input to FMS L0 DSM
Entries 571824
QT8(3) sum
QT board


Input to FMS L0 DSM
Entries 95304
QT8(3) sum - simulated
QT board


Input to FMS L0 DSM
Entries 571824
HT ADC
QT board


Input to FMS L0 DSM
Entries 95304
HT ADC - simulated
QT board


Input to FMS L0 DSM
Entries 571824
HT ID
QT board


Input to FMS L0 DSM
Entries 95304
HT ID - simulated
QT board


Input to FMS L1 DSM
Entries 142956
sumD
DSM board


Input to FMS L1 DSM
Entries 0
sumD - simulated
DSM board


Input to FMS L1 DSM
Entries 142956
sumC
DSM board


Input to FMS L1 DSM
Entries 0
sumC - simulated
DSM board


Input to FMS L1 DSM
Entries 142956
sumBC
DSM board


Input to FMS L1 DSM
Entries 0
sumBC - simulated
DSM board


Input to FMS L1 DSM
Entries 142956
sumB
DSM board


Input to FMS L1 DSM
Entries 0
sumB - simulated
DSM board


Input to FMS L1 DSM
Entries 142956
sumAB
DSM board


Input to FMS L1 DSM
Entries 0
sumAB - simulated
DSM board


Input to FMS L1 DSM
Entries 142956
sumA
DSM board


Input to FMS L1 DSM
Entries 0
sumA - simulated
DSM board


Input to FMS L1 DSM
Entries 142956
FMS L1 HT bits
DSM board


Input to FMS L1 DSM
Entries 0
FMS L1 HT bits - simulated
DSM board


Input to FPD L2 DSM
Entries 95304
quadrant sum
SMALL-ST SMALL-SB SMALL-NT SMALL-NB LARGE-ST LARGE-SB LARGE-NT LARGE-NB


Input to FPD L2 DSM
Entries 95304
quadrant sum - simulated
SMALL-ST SMALL-SB SMALL-NT SMALL-NB LARGE-ST LARGE-SB LARGE-NT LARGE-NB


Input to FPD L2 DSM
Entries 35739
CL bits
11913 11913 11913
SMALL LARGE-S LARGE-N


Input to FPD L2 DSM
Entries 35739
CL bits - simulated
11913 11913 11913
SMALL LARGE-S LARGE-N


Input to FPD L2 DSM
Entries 35739
HT bits
11913 11913 11913
SMALL LARGE-S LARGE-N


Input to FPD L2 DSM
Entries 35739
HT bits - simulated
11913 11913 11913
SMALL LARGE-S LARGE-N


Input to FPD L2 DSM
Entries 47652
jet patch sum (no FMS-LED)
0
20
40
60
80
100
120
ST
SB
NT
NB
1
10
10^2
10^3
10^4


Input to FE001 QT board
Entries 381216
ADC
channel


Input to FE002 QT board
Entries 381216
ADC
channel


Input to FE003 QT board
Entries 381216
ADC
channel


Input to FE004 QT board
Entries 381216
ADC
channel


TF201 0-15 (ch0)
Entries 190608
MTD ET ITE ITW TOFmult0 TOFmult1 TOFmult2 TOFmult3 TOFmult4 TOFsector0 TOFsector1 TOFsector2 TOFsector3 TOFsector4 TOFsector5 MTD-Cosmic


TF201 0-15 (ch0)
Entries 0
MTD ET ITE ITW TOFmult0 TOFmult1 TOFmult2 TOFmult3 TOFmult4 TOFsector0 TOFsector1 TOFsector2 TOFsector3 TOFsector4 TOFsector5 MTD-Cosmic


VT201 0-15 (ch1)
Entries 190608
BBC-TAC BBC-E BBC-W BBC-L-TAC BBC-L-E BBC-L-W ZDC-TAC ZDC-E ZDC-W ZDC-E-Front ZDC-E-Back ZDC-W-Front ZDC-W-Back VPD-TAC VPD-E VPD-W


VT201 0-15 (ch1)
Entries 38390
BBC-TAC BBC-E BBC-W BBC-L-TAC BBC-L-E BBC-L-W ZDC-TAC ZDC-E ZDC-W ZDC-E-Front ZDC-E-Back ZDC-W-Front ZDC-W-Back VPD-TAC VPD-E VPD-W


Unused (ch2)
Entries 190608


Entries 0


EM201 0-15 (ch3)
Entries 190608
BHT0 BHT1 BHT2 BHT3 EHT2 EHT4 JP1 JP2 BJP1 BJP2 EJP1 EJP2 AJP BAJP EAJP JP0


EM201 0-15 (ch3)
Entries 26
BHT0 BHT1 BHT2 BHT3 EHT2 EHT4 JP1 JP2 BJP1 BJP2 EJP1 EJP2 AJP BAJP EAJP JP0

RAT board (ch4)





FP201 0-15 (ch5)



FP201 0-15 (ch5)



ST201 0-15 (ch6)





Unused (ch7)






FP201 Channel 0 Bit Errors
Entries 190608
Number of Errors
Bit


FP201 Channel 1 Bit Errors
Entries190261
Number of Errors
Bit


FP201 Channel 2 Bit Errors
Entries 190608
Number of Errors
Bit


FP201 Channel 3 Bit Errors
Entries 190608
Number of Errors
Bit


FP201 Channel 4 Bit Errors
Entries 190608
Number of Errors
Bit


FP201 Channel 5 Bit Errors
Entries 190608
Number of Errors
Bit


FP201 Channel 6 Bit Errors
Entries 5781
Number of Errors
Bit


FP201 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM101 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM102 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM103 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM001 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM002 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM003 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM004 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM005 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM006 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM006 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM006 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM006 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM006 Channel 4 Bit Errors
Entries 190608
Number of Errors
Bit


FM006 Channel 5 Bit Errors
Entries 190608
Number of Errors
Bit


FM006 Channel 6 Bit Errors
Entries 190608
Number of Errors
Bit


FM006 Channel 7 Bit Errors
Entries 190608
Number of Errors
Bit


FM007 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM007 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM007 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM007 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM007 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM007 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM007 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM007 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM008 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM008 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM008 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM008 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM008 Channel 4 Bit Errors
Entries 190608
Number of Errors
Bit


FM008 Channel 5 Bit Errors
Entries 190608
Number of Errors
Bit


FM008 Channel 6 Bit Errors
Entries 190608
Number of Errors
Bit


FM008 Channel 7 Bit Errors
Entries 190608
Number of Errors
Bit


FM009 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM009 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM009 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM009 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM009 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM009 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM009 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM009 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM010 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM010 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM010 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM010 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM010 Channel 4 Bit Errors
Entries 190608
Number of Errors
Bit


FM010 Channel 5 Bit Errors
Entries 190608
Number of Errors
Bit


FM010 Channel 6 Bit Errors
Entries 190608
Number of Errors
Bit


FM010 Channel 7 Bit Errors
Entries 190608
Number of Errors
Bit


FM011 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM011 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM011 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM011 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM011 Channel 4 Bit Errors
Entries 0
Number of Errors
Bit


FM011 Channel 5 Bit Errors
Entries 0
Number of Errors
Bit


FM011 Channel 6 Bit Errors
Entries 0
Number of Errors
Bit


FM011 Channel 7 Bit Errors
Entries 0
Number of Errors
Bit


FM012 Channel 0 Bit Errors
Entries 0
Number of Errors
Bit


FM012 Channel 1 Bit Errors
Entries 0
Number of Errors
Bit


FM012 Channel 2 Bit Errors
Entries 0
Number of Errors
Bit


FM012 Channel 3 Bit Errors
Entries 0
Number of Errors
Bit


FM012 Channel 4 Bit Errors
Entries 190608
Number of Errors
Bit


FM012 Channel 5 Bit Errors
Entries 190608
Number of Errors
Bit


FM012 Channel 6 Bit Errors
Entries 190608
Number of Errors
Bit


FM012 Channel 7 Bit Errors
Entries 190608
Number of Errors
Bit